


ECO Chair High Chair Replacement Strap Instructions

Crotch Strap for the KB833

P/N 833-KIT

Hardware Supplied

Two #8 1/2" Self Tapping Screws



Tools Required:

Phillips Head Screwdriver

1. Using a sturdy table surface or the floor, place chair on its back with the crotch strap facing up. This will allow access to the crotch strap screws on the seat bottom.
2. Using a Phillips Head screwdriver, unscrew two screws attached to the old crotch strap. Remove screws and discard.
3. Grasping the strap below the high chair t-bar, pull upwards on the strap, gently gliding the strap through the seat slot. Remove the old crotch strap completely from the chair and discard the old strap.
4. To install the new strap, place the strap (buckle side up) through the slot in the cross bar at the front of the seat. Insert the bottom of the strap through the opening on the seat of the chair.
5. Once the strap is threaded through to the underside of the seat, thread the screw provided through the grommets on the strap. Using the existing holes on the seat bottom, tighten the screw into seat.
6. Gently pull on strap to ensure it is tightened properly and securely.

