

KB208 REPLACEMENT STRAP INSTRUCTIONS

P/N 208-KIT

Materials Supplied:

Two 3/8" Phillips Panhead Machine Screws
One Strap

Tools Required:

Phillips Head Screwdriver

1. Use a Phillips Head Screwdriver to remove the screws securing the old strap. Discard the old strap and screws.
2. Take the new strap and lay it on the unit. Position the strap so that the short end of the strap is towards the back of the unit.
3. Secure the strap to the unit by inserting one of the screws provided through the hole in the chafe tab and into the insert in the front of the unit.
4. Repeat the previous step for the opposite end of the strap.
5. Clean up work area and close unit.

