

KB318 and KB319 BISTRO HIGH CHAIR REPLACEMENT PURSE TRAY INSTRUCTIONS

P/N 1017-COLOR-KIT

Tools Required:

Phillips Head Screwdriver

Materials Supplied:

Purse Tray

Two Modified Truss Head Wood Screws

1. Using a Phillips Head screwdriver, remove the two screws that hold the purse tray to the lower leg rails.

2. Discard the old screws and purse tray.

3. Take the new purse tray and position it on the lower leg rails so that the vertical face is towards the front of the chair. Align the two holes in the purse tray with the holes in the lower leg rails (where the old screws were removed).

4. Using one of the wood screws provided, secure one side of the purse tray to the chair by screwing through one of the holes in the tray and into the hole in the lower leg rail.

5. Repeat step 4 on the opposite side of the purse tray.

