



KB208

Replacement Strap Instructions


P/N 208-KIT

Tool Needed




Phillips Head
Screwdriver

Hardware Provided



3/8" Phillips Panhead
Machine Screws
Quantity: 2



Strap
Quantity: 1




Fig. 1

Step 1:

- Use a Phillips Head Screwdriver to remove the screws securing the old strap. Discard the old strap and screws.

Step 2:

- Take the new strap and lay it on the unit. Position the strap so that the short end of the strap is towards the back of the unit. **Fig. 1**

Step 3:

- Secure the strap to the unit by inserting one of the screws provided through the hole in the chafe tab and into the insert in the front of the unit. **Fig. 2**

Step 4:

- Repeat the previous step for the opposite end of the strap.

Step 5:

- Clean up work area and close unit.




Fig. 2

Koala Kare Products
A Division of Bobrick

6982 South Quentin Street, Centennial, CO 80112-3945

Main: 303.539.8300 | **Toll Free:** 888.733.3456 | **Fax:** 303.539.8399

Website: koalabear.com | **Email:** customerservice@koalabear.com