DESIGNER HIGH CHAIR REPLACEMENT STRAP INSTRUCTIONS

Active Restraint Strap for the KB105-INB P/N 740-KIT-INB

Hardware Supplied

Two 5/8" Hex Head Machine Screws





Tools Supplied:

5/32" and 1/8" Allen Wrench

- 1. To enable you to remove the waist strap, slightly loosen the screws on the sides of the seat, but DO NOT REMOVE.
- 2. To remove the strap, turn the chair onto its side to reveal the underside of the seat. Unscrew the two screws from the two narrow chafe tabs on underside of the seat using the 1/8" Allen Wrench supplied. Discard the old strap and screws.
- 3. Loosen the side panels from the seat slightly using the 5/32" Allen Wrench supplied and pull the straps out through the slots on each side of the chair. Keep the wide middle strap in the slot.
- 4. To install the new strap, stand chair upright, place the strap on the seat. Thread the chafe tabs through the slots to the underside of the seat.
- 5. Once the straps are threaded through to the underside of the seat, thread the 2 Hex Head Machine Screws provided through the plastic chafe tabs. Tighten each screw into seat.
- 6. Slot the seat back into the sides and tighten the side bolts that were loosened in step 1. Ensure straps do not move from their position.







